

DC ARC MELTING FOR STUDIO JEWELRY CASTING


DC ARC MELTING HISTORY

DISCOVERY OF THE ARC

Sir Humphrey Davy



- Discovered the electric arc in 1801
- Melted metals and other materials in the arc 1810-1811.



Vasily Vladimirovich Petrov



- Rediscovered? the electric arc 1802
- Proposed the concept of arc

DC ARC MELTING HISTORY

SIR WILIAM SIEMENS



- Patented the arc melting furnace in 1878-79
- Reported on his demonstration furnace to the British Association for the Advancement of Science meeting in 1882




Fig. 4.




Fig. 5.

Patent Drawings

AC ARC MELTING TAKES OVER

- Héroult patented the AC arc furnace for steel production in 1900
- Due to the ease of providing large quantities of AC power AC furnaces replaced the DC furnace in large scale use for more than 90 years.
- Recent advances in power semiconductors have allowed a resurgence in large industrial DC furnaces.



Paul Héroult



**ARC MELTING IS THE STANDARD METHOD FOR
LARGE SCALE METAL MELTING**


WHY NOT SMALL SCALE?

ARC MELTING PROJECT

- This project grew out of my desire to melt and cast small amounts of metal in my studio a clean, oxygen-free environment.
- The use of a TIG torch seemed to be a possible way to do this

ARC MELTING FOR INVESTMENT CASTING 1916 US PATENT

- Proposed arc melting of metal for investment casting via vacuum assisted or centrifugal methods



- **CURRENT SMALL SCALE DC ARC MELTING**

- DC arc melting continues to be used for small scale laboratory and speciality furnaces
- These furnaces typically use a water-cooled copper crucible or hearth plate to limit contamination from refractory materials
- They provide vacuum or inert atmospheres around the melt



Cianflone Model 2701X arc button re-melt furnace

SMALL SCALE ARC MELT INVESTMENT CASTING

- There are also a few investment casting machines using arc melting for jewelry, dental or other small objects
- They use either graphite or water-cooled copper crucibles to melt in.
- Utilizing pressure over vacuum or centrifugal casting methods.



ARC MELTING FOR INVESTMENT CASTING

1956 US PATENT

- Crucible with conductive metal pin
- TIG torch suppling the arc

June 12, 1956


E. M. PROSEN

2,749,585

CENTRIFUGAL CASTING MACHINE FOR MAKING DENTAL CASTINGS


Filed Sept. 16, 1953

2 Sheets-Sheet 1



TUNGSTEN INERT GAS WELDING

- Also known as GTAW
Gas Assisted Tungsten Arc Welding
- A non consumable tungsten electrode is used to strike an arc to the work
- The heat of the arc creates a molten puddle to fuse the metal



TIG TORCH

- Can either be air or water cooled
- Collet assembly to firmly clamp tungsten for electrical and thermal conductivity
- Gas channels around collet cool the tungsten and provide inert atmosphere shielding for the weld



*Water Cooled TIG
Torch*

130 AMP POWER SUPPLY

- Advances in power semiconductors have made small power supplies very affordable



INITIAL ATTEMPTS

- Using a graphite hearth had mixed results, some alloys worked well others were very oxidized
 - Oxidation from turbulence in inert gas stream
 - Thermal losses to graphite crucible and copper plate



GAS LENS VS STANDARD COLLET BODY

- The gas lens was invented to reduce turbulence in shielding gas stream
- Even with the laminar flow turbulence is still an issue in the crucible
- What is the answer?



A CONTROLLED ATMOSPHERE CHAMBER



VACUUM PURGED GLOVE BOX

- Vacuum purged below 26pa and backfilled with argon.
- Chamber O₂ levels below 0.1ppm easy to achieve
- Airlocks to bring items in and out of the chamber



Glove Ports Open




INTERNAL WORKSPACE




CRUCIBLE & ELECTRODE

The concept of the crucible with a conductive rod in the base dates back to Siemens original patent



GRAPHITE ELECTRODE



- Copper sheathed graphite rod
- Reaction with crucible from secondary arc.




TUNGSTEN ELECTRODE

- Provides electrical contact to metal for melting.
- Works best with lower melting point metals (below 2000F)



WATER COOLED ELECTRODE


- Uses a modified TIG torch to hold the electrode.
- Allows the use of tungsten or consumable electrodes made from the same metal as is being melted.



CONSUMABLE ELECTRODE


- Like the tungsten electrode it provides electrical contact to metal for melting.
- Eliminates the possible contamination of the melt by tungsten






TI RESEARCH-CAST/T MACHINE

CASTING FLASK



*Flask spins on central axis
@ 930 RPM*



Ti Research

ARC MELTING AND CASTING PD950

<https://www.youtube.com/watch?v=ya5wJFcd2DU&feature=youtu.be>

TUNGSTEN ELECTRODE

316 STAINLESS

<https://www.youtube.com/watch?v=TwxsZqfa2ew&feature=youtu.be>

CONSUMABLE ELECTRODE MELT




METALS SUCCESSFULLY MELTED AND CAST

- Palladium 950 T (some issues with contamination silica? tungsten? both?)
- Sterling Silver T, C
- 18K Yellow T
- 14K Red, 14K Palladium White T
- Copper T, C
- 316 Stainless Steel T, C

T= Tungsten C=Consumable

COMPARISON WITH INDUCTION



INDUCTION MELT 316 STAINLESS




	Power	Time to melt	Cost
DC Arc	3.6 kW 20 Amp 220 Single Phase	34 Sec	\$7K to \$10K
Induction	5kW Out 50 Amp 220 3Phase	20 sec	\$15K-\$50K

POSSIBLE ARC MELT/CAST CONFIGURATIONS

VACUUM PURGED GLOVEBOX

- Chamber purged by vacuum and backfill with inert gas
- Low gas usage
- Vacuum air lock to move flasks in and out.
- Have to work with gloves



GAS PURGED GLOVE BOX

- Chamber purged by flowing a large volume of inert gas to reduce O₂ to acceptable level
- Vacuum air lock to move flasks in and out.
- Less stringent materials requirement for box
- Much greater gas usage
- Still have to work through glove ports




HANDHELD MELTING CHAMBER

- Arc version of the typical hand held melting furnace
- Quartz cylinder to shield melt from outside atmosphere during melt
- Some metals would not work as well due to greater oxygen presence during pouring



PURPOSE BUILT SYSTEM

- Variation on lab button melter.
- Motor on outside of chamber
- Small volume of gas to deal with for quick cycle time.
- No gloves



WHAT'S NEXT?

- Additional metals
- Build some different systems
- Melt temperature control

THANK YOU

Eddie Bell

The Santa Fe Symposium Staff

Linus Drogos / Au Enterprises

And special thanks to my wife Terry for all her help
and understanding